

ML1 hearing loop system (Can be interfaced to a Type B outstation's loop connectors to assist hearing aid users in an emergency situation)

Part No. **ML1/K**



Overview

Ideal for banks, post offices, small meeting rooms, reception desks, ticket booths and any other application requiring restricted or small area coverage.

Requires no specialist audio experience or connectors - can be fitted by any competent electrician.

Space-saving double-gang wall-mounting amplifier fits standard UK 25mm back boxes (requires fixed mains wiring).

Omni-directional AMT microphone (supplied) plugs directly into the 3.5mm socket on the amplifier's front.

Line/outreach socket also provided (max 3 outreach plates per system).

User-adjustable mic. sensitivity and engineer-adjustable loop drive and input level controls.

Technical Specifications

Type	Wall-mounting (requires fixed mains wiring and a 25mm back box).
Coverage	12m ² approx.
Mains supply	The general requirement for the 230V a.c. Mains supply to the ML1 is fixed wiring, using 3 core cables of not less than 1mm ² fed from an isolating switched fused spur, fused at 3A.
Max battery size and type	n/a.
Auxiliary inputs	1 x 3.5mm remote mic. socket; 1 x Line/Outreach socket (max. 3 Outreach plates per ML1).
Indicators	Input level; power on; loop drive meter.
Controls	Mic. input level, line input level; loop drive,
Product dimensions (mm)	W 143 x H 83 x D 32mmL.
Construction & finish	Plastic.
IP Rating	IP20.
Weight	300g (amplifier only).