

Portable hearing loop kit c/w amplifier, plugtop charger & wall mount shelf

Part No. **PL1/K1**



Overview

New for 2017 - the PL1/K1 is now supplied with a robust wall-mounting storage shelf.

Ideal for restricted person to person contact in areas such as banks, post offices, small meeting rooms, reception desks, open plan offices and ticket booths.

Portable, lightweight design means the system can be moved easily from location to location.

Simple one button operation.

Integral high performance microphone.

Excellent sound quality.

Five years' expected battery life under normal operating/charging conditions.

Auto shut-off facility (user selectable for 10, 30 or 60 minutes) helps preserve battery life.

Connection of the plug-top charger overrides the timer function to ensure the unit remains operational at all times.

Unit can be used as normal whilst charging.

Technical Specifications

Coverage	1.2m2 approx.
Application/operation	Portable.
Mains supply	Kit includes a 230V a.c. plugtop charger.
Max battery size and type	Amplifier includes an Integral 12V Valve Regulated Sealed Lead Acid battery.
Auxiliary inputs	2 x Mic (one built-in mic and one 3.5mm remote mic socket for AMT or AMD microphones).
Indicators	Power on; input level; charging required; charging in progress; audio-warning of imminent shutdown.
Controls	On/off button; adjust auto-shut off timer (note: the auto-shut-off function only applies when the plugtop charger is not connected to preserve battery life).
Product dimensions (mm)	W 271 x H 200 x D 77mm (amplifier). Shelf measures W 260 x H 263 x D 140mm.
Construction & finish	Black plastic amplifier with blue 'AFILS' available label; black high impact polystyrene shelf.



IP Rating	IP20.
Weight	2.82kg (amplifier); 360g (shelf).
Kit contents	PL1 amplifier; plug-top charger; wall mounting storage shelf.



T 01942 322744 E sales@c-tec.co.uk
F 01942 829867 W www.c-tec.com



C-TEC, Challenge Way, Martland Park, Wigan, WN5 0LD United Kingdom