

50m2 Domestic Hearing Loop System

Part No. **DL50/K**



Overview

Free-standing - ideal for bedrooms, living rooms, TV lounges, studies and other domestic applications.

Includes a DL50 amplifier, plug top power supply, loop cable, SCART to double phono lead, AMT microphone and AFILS fitted sticker.

Simple to adjust and tamper-resistant drive, level, tone and microphone priority controls

Input peak, output current, signal present and power on LEDs.

Alert tone input for doorbells, fire alarms, security systems, etc.

Meets and exceeds the requirements of BS7594 and EN60118-4 when correctly installed.

Technical Specifications

Type	Free-standing. Plugtop mains lead supplied.
Coverage	50m ² approx. (note that loops over 16m ² may require two turns of loop cable).
Mains supply	Plugtop mains lead supplied.
Max battery size and type	n/a.
Auxiliary inputs	2 x 3.5mm remote mic. socket; 1 x dual phono (line) socket; Alert input
Indicators	Input level; loop current meter; power on.
Controls	Input level; loop drive, tone, microphone priority
Product dimensions (mm)	W 185 x H 40 x D 85mm (amplifier only);
Construction & finish	Black metal; grey label.
IP Rating	IP20.
Weight	550g
Operating conditions/temperature	-5°C to +40°C. Max relative humidity: 95%.